

# MEDIUM LED CUTOFF WALLPACK MLCWP INSTALLATION INSTRUCTIONS



## WARNING

Please read instructions carefully before attempting to install fixture and retain instructions for future reference.

Caution: To avoid electrical shock hazard.

- Turn off the electricity before installing or servicing this fixture.
- Electrical connections need to comply with National Electric Code and Local Electric Code.
- The fixture should be installed by a qualified electrician.
- Do not touch the yellow portion of the LED array. Damage may occur.
- Do not wire fixture until fixture is mounted.
- Use wire rated for at least 80°C.

## APPLICATION/USE

This product is rated for use in wet locations and designed for surface mounting only. It is best to mount the fixture to a standard 4" electrical box. If a different size electrical box already exists to the mounting location, you may need to purchase additional equipment for installation.

## INSTALLATION

1. Remove front housing by loosening four screws, swing front housing open.
2. Drill appropriate knockouts from back of fixture for wiring access.
3. Knock out appropriate holes around outlet hole.
4. Apply weatherproof silicone sealant around mounting box edges for enhanced moisture ingress protection.
5. See "Fixture Wiring"
6. Replace front housing, connect connector, and swing front housing into position. Tighten screws which were loosened in Step 1.

## FIXTURE WIRING

1. Connect the black fixture lead to the voltage supply lead with wire connector.
2. Connect the white fixture lead to the neutral supply lead with the wire connector.
3. The fixture must be grounded. Connect the supply ground to the fixture green ground screw.
4. Cap and insulate all unused leads.

Need help? Call 1.800.956.3456 to speak with our installation and product experts.