

INTRODUCTION

Your FrontRow Pro Digital system is the audio center of your classroom! Connect your computer, TV, VCR, computer, CD player, MP3 player and other teaching technology to your system to allow children to hear the teacher's voice and the rich multimedia content that is being played, regardless of where they're seated.

The Pro Digital receiver has two auxiliary audio inputs and the 940TM Pendant Microphone has one auxiliary audio input. They both use industry standard connectors and ship complete with the necessary audio cables. Integrating your classroom couldn't be easier!

And don't forget, with the FrontRow Pro Digital receiver you can now Podcast by connecting the "Audio Out" from the receiver to the "Audio In/Microphone" to the computer. See our other guide "Podcasting with the FrontRow Pro Digital" for more information.

frontrow™


pro digital

integration tips

OPTION 1

Many classrooms use a computer as a multi-media "hub" (with an LCD projector), which is connected to the internet or school network to download/stream audio and video, and also play MP3 files. For these classrooms, you may only require one auxiliary audio input connection to the Pro Digital. The other audio input can be connected to other media, such as an iPod® or CD player.


NOTE: Connect the "Audio Out" from the Pro Digital to the "Microphone" input on your computer (for podcasting).



OPTION 2

Some classrooms use a computer as the multi-media "hub", but it is connected to a TV instead of an LCD projector. They also occasionally use the TV/DVD/VCR as a stand alone medium. For these classrooms, you may need to use both auxiliary audio input connections to the Pro Digital receiver.


NOTE: Connect the "Audio Out" from the Pro Digital to the "Microphone" input on your computer (for podcasting).



OPTION 3

Some classrooms may have many different types of media, but because of the age of the equipment or incompatible input/outputs, they may not integrate easily with each other. For these classrooms, you may choose to use an auxiliary audio box (available from FrontRow) to connect all the sources to one location, then connect it to one audio input connection to the Pro Digital Receiver.

NOTE: Connect the "Audio Out" from the Pro Digital to the "Microphone" input on your computer (for podcasting).



OPTION 4

The 940TM Pendant Microphone has an auxiliary audio input so you can connect it to any audio source and then "broadcast" it to the ProDigital receiver. This is completely independent from and in addition to the auxiliary audio inputs connected to the back of the receiver. Using this option, teachers can easily connect to infrequently used audio sources, or portable devices, such as an iPod®. Fix the volume on the audio device and use the "Microphone A/B" volume control to adjust the volume.

NOTE: Connect the "Audio Out" from the Pro Digital to the "Microphone" input on your computer (for podcasting).

